

## BATTERY GUARD 12V / 140 AMP

Art.no: 16-990200

Battery guard that protects your starting battery or auxiliary battery from discharge, ensuring that the battery remains charged and prevents the engine from not starting due to battery discharge. Ideal for use in systems where, for example, an inverter is connected. When the voltage drops below 12.65 VDC, the battery guard disconnects. When the battery voltage returns to 13.3 VDC, it reconnects the circuit.

### Technical information

Voltage	12V
Current	120A
Dimensions (LxHxW)	68 x 68 x 55 mm
Warranty	1 Year
Number of pins	2
Weight (kg)	0.100000

